

# S066 User Manual



## **Warning:**

This device is recommended to use in house. Don't use this device in high temperature and poisonous environment. Don't put this device into water to avoid damage. Inserted battery, and don't put the device close to fire to avoid exploding. Don't repair and change the device yourself avoid losing warranty. Don't use for long time, especially in high volume, which will hurt your ear.



## **Important safety notice**

1. Please read the User Guide.
2. Please save the User Guide
3. Please pay attention to the Warning
4. Please use the device according to the User Guide
5. Don't use this device exceed the function definition.

## **Specification**

Support Bluetooth call, FM, time display.

ode/Device name: HOTT

Bluetooth Version: BT5.0

Range: 10m (Free space)

Output power: 3W

Frequency: 20Hz~20kHz

SNR:  $\geq 80$ dB

Battery capacity: 3.7B 1000mA

Play time: >10H (Default volume)


Charging time: 3~4h

Inserted MIC

IPX4 waterproof

Micro USB interface  
Charging IN: DC 5V  
Packaging;  
Bluetooth kit  
Micro USB cable  
User Guide

## Product Diagram



## Main function



1. Press power key for 3s to power on or off.



2. Short press can play/ pause. Disconnect Bluetooth in

BT mode.



3. Volume up/ Next



4. Volume down/ Previous




5. Answer/Reject/Dial call

6. Screen display user interface



7. Charging with USB cable, connect to DC 5V or PC.

8. Blue LED on when working, Red LED on when charging.

9.  FM/M mode change, BT  FM  Time

10. MIC whole

Charging can reset the device if work abnormally.

## **Product operation**

### **A. Running station**

Press the power button for 3 seconds, hear the warning tone, the blue led will flash, and it will be on if connected successfully.

### **B. Power off**

Press the power button for 3 seconds, after hearing the warning tone, the device will power off.

### **C. Bluetooth pairing**

If not connected before, you need connect your loudspeaker box with the Bluetooth device according the program below.

1. Power on, after hearing the warning tone, the box will be in pairing mode, and the blue led will flash.
2. Activate your Bluetooth device, and search.
3. Select the box name, which was searched by your Bluetooth device.

**Notice:** If the box is being connected with other device, you need disconnect, and search again.

4. The password is "0000" if need, and choose "OK". The password would be different between different manufactures.
5. If paired successfully, the blue led will be on all the time. Now,

you can use your box to play music and call. When playing the music, the blue led will breath slow. When pause the music, the blue led will flash several seconds, the be on all the time.


**Notice:**


If connected with the box before, you need connect according to the instruction below.

Activate Bluetooth function in your device, the loudspeaker box will connect with your device automatically and can hear the warning tone.



## **Play music after Bluetooth connecting**

Short press  to play and pause if playing.

Long press  to play next, and short press to volume up.

Long press  to play previous, and short press to volume down.

## **Hands free call mode**

If connected, you can press  to answer the call, and press  to hang up when talking. At the same time, music will stop automatically.


## **Charging for the loudspeaker box**


Battery inside, can connect the USB cable to PC to charge the box, or connect the USB cable to DC 5V adaptor. When charging, the red led will be on. If charging finished, the red led will be off. Please remove the cable.



The working time will depend on the volume level, the higher volume, the shorter time. You need re-charge the box if you didn't use it for a long time. It's recommended to charge the box once per month, so that can protect the battery better, and the battery will work for longer time.





## FM mode




Long press  to FM scan mode, and save automatically.




Short press  can play the channel saved.

Long press  to change the channel saved, long press  to delete the channel.

Long press  /  to modify frequency, short press can change volume.

## Time mode

Press change key into time mode, long press  and type 12h/24h system, press  /  to change.

Short press  to M/S mode and short press  /  to set time.

## Absorbed function when having a bath

When having a bath, can listen to the music and answer the call, as the product can absorb the wall with the pedestal.

### Notice:

Don't dip the product into water, which will damage the product.

### Capacity

Bluetooth version: BT5.0, support profile: A2DP /HFP/AVRCP



This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC ID: YB2-S602

## Question and instruction

If find some problem when using this product, you can solve according to the solution below.

Trouble	Trouble shooting	Solution
Charge failure	USB power charger (not included in this package ) is not inserted into the wall socket or USB cable (included in the package) is not inserted into the 2.0mm interface on the side of the speaker	Insert the charger into the wall socket or USB cable into the 2.0mm interface on the side of the speaker
	The wall socket doesn't work.	Insert the device into another wall socket to make sure the playback fails
	The USB port of the computer doesn't work.	Make sure your computer is turned on and try another USB port.

There is no sound	The battery in the speaker is dead	Recharge
	Phone not connected.	Read the "speaker actions" section to connect speakers
	Volume is too low.	Volume up your product
Can't connect with the product.	Can't pair	Check your Bluetooth device if support A2DP profile
	Sound source off	Open the sound source/
	The Bluetooth is off	Open the Bluetooth in your device
	Bluetooth is incompatible	Use different play device
Poor quality/ interrupt	The device exceeds the range	10m in free space.

Notice, all the information above only for your reference.

# S066 中文参考说明书

## 警告

此设备只限于室内使用。

请不要在高温或者有毒环境下存放或者使用此设备。

请勿将设备浸于水中，会损坏机器。

设备内含可充电电池，所以请不要将其放在火上，以免发生爆炸；

保修范围不包括因用户擅自修理、修改的情况。

不要长时间地在高音量下听音乐，这有可能会损害你的耳朵；

## 重要安全提示

1. 请阅读指导说明；
2. 请保存指导说明；
3. 注意所有的警告部分；
4. 遵循所有的指导说明；
5. 除该设备的定义的功能使用以外，请不要用此设备用于其它用途。

## 规格:

(支持蓝牙通话功能, FM 收音, 时钟显示功能)

型号/设备名称: HOTT

蓝牙版本: BT5.0

传输距离为 10M (根据周围环境的不同传出距离也会有所不同)

输出功率: 3W

频率: 20Hz - 20KHz

信噪比:  $\geq 80$ dB

内置电池: 3.7V 1000MA

播放时长: 默认音量 $>10$ H

充电时间: 3-4H

内置麦克风

IPX4 防水等级


Micro USB 充电接口

充电输入: DC5V

## 包材:

说明书      蓝牙音箱      Micro USB 充电线

## 产品图解



## 主要功能



1. 长按电源键 3 秒进行开/关机。



2. 短按可选择播放或者暂停音乐。蓝牙模式长按断开蓝牙



3. 音量增加/下一曲



4. 音量减小/上一曲




5. 接听/挂断/拨打电话

6. 显示屏 显示界面模式功能



7. 使用配带的 USB 线来充电，连接 DC5V 充电器或者电脑都可进行充电。

8. 蓝色 LED 灯亮时表示正在工作，红灯表示充电。

9.  模式切换键，蓝牙-FM 收音-时钟模式顺序切换

10. 麦头孔

. 如果设备无法工作，请插入 USB 充电激活设备。



## 音箱操作

### A. 开机状态

长按电源键 3 秒，将听到提示音，蓝色指示灯将开始闪烁，一旦配对成功，蓝灯显示为长亮，

### B. 关机

长按电源键 3 秒，将听到提示音，机器将处于关闭状态。

### C. 蓝牙配对

如果蓝牙音箱从未与设备连接过，你需要遵循以下指导来将音箱与你的蓝牙设备进行连接。

1. 开机，在听到提示音后，蓝牙音箱将进入蓝牙配对模式，且蓝色指示灯将一直闪烁。
2. 激活你的蓝牙设备，让其开始搜索要配对的蓝牙设备名称。
3. 从发现的蓝牙设备名称列表中选择蓝牙设备名称。

**注意：**如果该设备已经连接到另外一台蓝牙设备，那么蓝牙音箱设备将不会出现在列表里面，你需要将已经连接的蓝牙设备断开，并再次搜索。



4. 如果你的设备询问密码, 请输入数字 0000 并且选择 OK (会随着不同的蓝牙制造商, 型号及软件版本不同而不同)



5. 如果配对成功了, 蓝牙音箱指示灯为蓝色长亮, 而不是快速闪烁。此时你的蓝牙音箱可以进行音乐播放以及接听手机来电。当你播放音乐的时候, 蓝色 LED 灯将缓慢闪烁。当暂停音乐时指示灯将缓慢闪烁几秒, 然后保持长亮。

**注意:** 如果音箱以前连接过蓝牙设备, 则需要遵循以下指导来进行蓝牙连接: 在要配对的设备上激活蓝牙, 蓝牙音箱将自动连接到你的蓝牙设备, 将听到提示音。



## 蓝牙模式下的音乐播放

蓝牙连接成功后, 短按一次  播放音乐, 再短按  为暂停音乐,

长按  为播放下一首歌曲, 长按  为播放上一首歌曲。

短按  为加大音量, 短按  为减小音量。

## 将音箱用作免提蓝牙电话

当你的蓝牙设备已经与音箱配对后，如果有来电或者去电，音箱会自动从音乐播放模式转到电话模式。如果有来电，短按  来接听电话。完成通话后，再短按一次  来挂断电话。通话结束后，音乐将自动继续播放。


## 音箱充电




音箱内置可充电电池，用自带的 USB 线来连接电脑，或者 DC 5V 的充电器来充电。当音箱处于充电状态时，充电指示灯变成红色。当音箱充满电时，红色 LED 灯将关闭。充满电后，请将音箱从电源上拔下。



电池的播放时间取决于播放时的音量大小（音量越大，播放时间越短）。如果长时间没有使用蓝牙音箱，则在重新使用前请充电。我们也建议一个月充一次电，这样可以保护电池，延长电池的寿命。

## FM 模式

按切换键进入 FM 收音模式




长按  键，进入自动收台模式，自动搜索到的电台，会自动保存。

自动保存的电台，短按  键，可以按顺序切换播放不同的电台  
长按  模式切换键可以保存当前电台，长按  键可以删除已保存的电台。

长按  /  可以手动调节频率，短按时可以调节音量的大小

## 时钟模式

按切换键，进入时钟模式长按  键进入 12 小时/24 小时制，按  /  键来切换。

短按  键，进入时/分数字调节模式，短按  /  手动调节所需的数字时间

## **淋浴及吸附功能**

在淋浴过程中可以享受音乐，接听来电。底部的吸盘可以吸附在任何光滑的平面。

### **注意：**

不要将产品浸入水中，这将损害音箱。

## **兼容性**

蓝牙版本 BT5.0，支持 A2DP /HFP/AVRCP.

## 问题解决指导

如果在使用音箱的过程中，遇到麻烦，请参照以下表格来解决：

故障	分析	解决方案
不充电	USB 电源充电器（此包装不含）没有插入到壁式插座里面或者 USB 线（包装含）没有插入到音箱侧面的 2.0MM 的接口里面	将充电器插入到壁式插座里面，或者将 USB 线插入到音箱侧面的 2.0MM 接口里面。
	壁式插座不灵	将设备插入到其它的壁式插座里面，以确认是播放失效。
	电脑的 USB 接口不工作	确保电脑是开机状态，尝试另一个 USB 接口
没有声音	音箱的电池没电	重新充电。
	未连接手机。	阅读“音箱操作”部分来连接音箱。
	音量太小	增大你的设备音量。

音箱无法连接	配对不成功	检查蓝牙设备是否支持 A2DP 协议。
	音源已经关闭	打开音源。
	音源的蓝牙已经关闭。	在音源处打开蓝牙。
	蓝牙版本不支持	使用不同的播放装置
音质差 / 断音	蓝牙设备已经超过可传输的有效距离	距离 10 米范围

注：以上所有内容说明只作参考。

